

Aluminum Combination Ladder user guide

SW-1203-07/09/11 series

Content

- Aluminum Combination ladder
- Aluminum step ladder with an extending ladder at the top mode
- Extension ladder mode
- Single ladder
- Danger
- Maintenance

Aluminum Combination ladder

Aluminum Combination ladder can be functioned as

- 1) Aluminum Step ladder with an extending ladder at the top
- 2) Aluminum extension ladder.
- 3) single ladder by taking the top ladder section from the ladder system and use separately

Part list

- 1 x 3 sections combination ladder
- 1 x stabilizer
- 2 x bolts & nut kit



Aluminum Step Ladder with an Extending ladder at the top

Set up

- Install the stabilizer to the bottom ladder section with bolt and set.(Fig1.)
- Check and open the red safety latches at the bottom ladder section hook.(Fig2.)
- Push the middle ladder section upward so that the rung of the middle ladder section out of the hook.
- Move the middle ladder section slightly in order the pivot on the top of the ladder section slide into the notch on the top of the bottom ladder section.(Fig3.)
- Pull the middle ladder section outward to step ladder mode until the nylon webbing strap tighten.(Fig4.)
- Open the red safety latches at the middle ladder section hook, to adjust the high of the top ladder section to your desire high. The rung of the top ladder section need to be fully sitting into the hook of the middle ladder section.(Fig5.)
- Lock the red safety latches of the middle ladder section hook so that the top ladder section will not move even with an upward push.(Fig6)
- Make sure the red safety latches have been lock the rungs before using the ladder



Fig1



Fig2



Fig3



Fig4



Fig5




Fig6

Aluminum Extension ladder

Set up

- Install the stabilizer to the bottom ladder section with bolt and set.(Fig1.)
- Check and open the red safety latches at the top ladder section hook.(Fig2.)
- Push the top ladder section upward so that the rung of the top ladder section out of the hook, to adjust the high of the top ladder section to your desire high. The rung of the top ladder section need to be fully sitting into the hook of the middle ladder section.(Fig3.)
- Lock the red safety latches of the middle ladder section hook so that the top ladder section will not move even with an upward push.(Fig4)
- Open the red safety latches at the bottom ladder section hook, to adjust the high of the middle ladder section to your desire high. The rung of the middle ladder section need to be fully sitting into the hook of the bottom ladder section.(Fig5.)
- Lock the red safety latches of the bottom ladder section hook so that the middle ladder section will not move even with an upward push.(Fig6.)
- Make sure the red safety latches have been lock the rungs before using the ladder



Fig1



Fig2



Fig3




Fig4




Fig5




Fig6

Aluminum Single ladder set up

Set up

- The top ladder section could be taken out from the ladder system as a single ladder.
- Reset the ladder back to closed mode(Fig1.)
- Check and open the red safety latches at the top ladder section hook.(Fig2.)
- Push the top ladder section upward so that the rung of the top ladder section out of the hook.
- Pull the top ladder section from the bottom until it separated from the rest ladder system.(Fig3.)



Fig1




Fig2





Fig3

Danger



Warning: Never use the ladder as extension ladder and step ladder without stabilizers, stabilizers need to fit on the notches of the ladder section and the bolts need tighten.



Maintenance

- Always store the ladder in dry location
- Keep rails clean.
- Check all components to be sure they operate correctly
- Replace labels with label kit when labels become obscure defaced, missing or difficult to read.